

GUH95T-95C "ECM" GAS FURNACES M SERIES

DESCRIPTION	PART NUMBER	USED ON THESE MODELS
102703-02 Wheel-Blower 11 X 11 X 1/2	69W50	GUH95C(045,070)B3M, GUH95T(090C,110C,135D)5M
LB-29333BM WHEEL	16596	GUH95C090C4M
LB-29333BCW WHEEL-BLOWER	36M22	GUH95C(110C,135D)5M
102712-01 Wheel-Blower 10 X 9 X 1/2	69W52	GUH95T(045B,070B,090C)3M
102809-02 Hose Drain	71W36	GUH95C(ALL)M, GUH95T(ALL)M
102809-03 Hose Drain	98W72	GUH95C(ALL)M, GUH95T(ALL)M
610587-03 Module Kit	10B70	GUH95T045B3M
610587-05 Module Kit	10B72	GUH95T070B3M
610587-06 Module Kit	10B73	GUH95T090C3M
610587-17 Module Kit	10B84	GUH95T090C5M
610587-18 Module Kit	10B85	GUH95T110C5M
610587-19 Module Kit	10B92	GUH95T135D5M
Inducer Assembly	93W13	All Models
607421-02 X13 1/2HP Motor - Programmed	81W33	GUH95C(045,070)B3M
607421-06 X13 3/4HP Motor - Programmed	81W37	GUH95C090C4M
607421-11 X13 1HP Motor - Programmed	81W42	GUH95C110C5M
607421-08 X13 1HP Motor - Programmed	81W39	GUH95C135D5M
610588-01 Motor Kit	10B66	GUH95T(045B,070B,090C)3M
610588-02 motor kit	10B67	GUH95T(090C,110C,135D)5M
MOUNT-MOTOR	18M68	GUH95C(045B3,070B3,090C4)M, GUH95T(045B,070B,090C)3M
MOUNT-MOTOR	32M17	GUH95C(110C,135D)5M, GUH95T(090C,110C,135D)5M
ARM-MOTOR MTG	49L97	GUH95C(110C,135D)5M, GUH95T(090C,110C,135D)5M
102907-01 Roll Out Switch (210F)	71W49	GUH95C(ALL)M, GUH95T(ALL)M
102837-01 VALVE-GAS	73W17	GUH95C(ALL)M
103181-02 VALVE-GAS (2 STG NAT)	83W12	GUH95T(ALL)M
100597-01 Breaker-Circuit	26W34	GUH95C(070B3,090C4,110C5,135D5)M
607436-02 Kit -Ignition Control Board	16C81	GUH95C(ALL)M
607308-14 KIT-IGNITION CONTROL	14Y53	GUH95T(ALL)M
102317-01 SWITCH-INTERLOCK	51W15	GUH95C(ALL)M, GUH95T(ALL)M
602866-04 Burner Assy (045)	69W87	GUH95C045B3M, GUH95T045B3M
ASSY BURNER (6)	69W88	GUH95C070B3M, GUH95T070B3M
ASSY BURNER (8)	69W89	GUH95C090C4M, GUH95T(090C3,090C5)M
ASSY BURNER (10)	69W90	GUH95C110C5M, GUH95T110C5M
ASSY BURNER (12)	69W91	GUH95C135D5M, GUH95T135D5M
LB-94726J HOUSING-BLOWER	57M87	GUH95C(045,070)B3M

DESCRIPTION	PART NUMBER	USED ON THESE MODELS
LB-94726K HOUSING-BLOWER	57M88	GUH95C090C4M
LB-94726L HOUSING-BLOWER	57M89	GUH95C(110C,135D)5M
LB-94726T HOUSING-BLOWER	70W40	GUH95T(045B,070B,090C)3M
LB-94726X HOUSING-BLOWER	70W42	GUH95T(090C,110C,135D)5M
LB-74940B Flame Sensor Kit	69W43	GUH95C(ALL)M, GUH95T(ALL)M
104371-01 SWITCH - PRESSURE .65	10U93	GUH95C045B3M
104106-02 Pressure Switch Kit.90	10U94	GUH95C(070B3,090C4,110C5,135D5)M
104549-11 Pressure Switch 2-STG-.70/- .40	14A53	GUH95T045B3M
104549-06 Pressure Switch 2-STG-.85/- .50	14A48	GUH95T(070B3,090C3,090C5)M
104549-03 Pressure Switch 2-STG-.90/- .50	14A45	GUH95T110C5M
104549-01 Pressure Switch 2-STG-.90/- .45	14A43	GUH95T135D5M
42J3201 TRANSFORMER	42J32	GUH95C(ALL)M, GUH95T(ALL)M
LB-112237B IGNITER	70W16	GUH95C(ALL)M, GUH95T(ALL)M
102857-07 Control-Limit (175F)	73W20	GUH95C045B3M, GUH95T(045B,090C)3M
102857-08 Control-Limit (165F)	75W15	GUH95C070B3M, GUH95T070B3M
102857-06 Control-Limit (155F)	73W19	GUH95C090C4M
102857-04 Control-Limit (145F)	71W44	GUH95C110C5M, GUH95T135D5M
102857-03 Control-Limit (140F)	71W43	GUH95C135D5M
102857-05 Control-Limit (150F)	73W18	GUH95T(090,110)C5M
102906-02 Orifice-LP .034	71W48	GUH95C(ALL)M, GUH95T(ALL)M
605099-07 DRAIN TRAP (GOODY BAG)	95W17	GUH95C(ALL)M, GUH95T(ALL)M