
WIRING DIAGRAM

Gas Direct Ignition Furnace, Heating & A/C Ready, MG1E All Models.

- NOTES: 1. Incoming power must be polarized. Observe color coding. (See furnace data label for electrical information.)
- 2. If any of the original wires (as supplied with the appliance) must be replaced, use 105°C Thermoplastic type wire or its equivalent.
- 3. A wire from "Y" on the thermostat to the furnace is required.



CONTROL LIGHT STATUS

RED