Installation Instructions

MARS No. 68040

MARS Universal Hot Surface Igniter

WARNING!

We strongly recommend that the installation is carried out by a qualified gas appliance service provider.

Follow the recommended installation instructions carefully. Failure to do so will void the warranty and may lead to injury or property damage. **Shock Hazard:** Always turn off electric power before working on any appliance. Ensure proper connection to all wires. **Explosion Hazard:** Shut off gas to appliance before installation begins, and do not reconnect until installation is complete. **Fire Hazard:** Ensure that components do not come into direct contact with water. Ensure that wiring is routed securely, and away from any flame.


Igniter Specifications:

Time to 1200°C < 6 seconds @ 120 volt
Cold Resistance 8-15 ohms @25°C
Operating Voltage Power Rating 100 - 160 watts

Installation Instructions

Please read all these instructions to the end carefully before beginning installation.

- 1. Turn off the gas and electrical supply and then identify which type of igniter is inside your appliance.
- 2. Unplug your existing igniter retaining all fittings, and match it up with the diagrams.
- Compare the position of the alignment tag on your existing igniter carefully to the top view diagrams. Ensure that you have the correct igniter type.
- 4. Referring to the diagram, break off the tabs indicated, preferably with thin nose pliers.
- 5. Cut off the connector from your old igniter, as close to the base as possible. Strip the wires.
- Fit the universal adaptor bracket to the appliance using existing screws. Screw the igniter into adapator, using the screw provided.
- Attach the wires from the appliance onto the igniter, by twisting the stripped ends together, matching one wire from the igniter to one wire from the appliance.
- 8. Take the wire nuts provided and screw down tight over the joined stripped wires, ensuring that no wires are showing.
- Check installation is secure and safe, routing leads away from the burner.



(continued on back)



Installation Instructions MARS No. 68040 MARS Universal Hot Surface Igniter

(continued from front)

